

Manual CUTTING

MT-125, 6m: 595039506, 12m : 595039513

Fine Cut 45 A			595039315 (X5)		595039322
45 A	595039131		595039162 (X5)		
65 A		595039155 (X5)	595039179 (X5)	595039216	595039230
85 A			595039186 (X5)		
105 A	595039148		595039193 (X5)	595039223	595039247

Automatic CUTTING

AT-125, 6m: 595039479, 12m : 595039520

Fine Cut 45 A			595039315 (X5)		595037496
45 A	595039131		595039162 (X5)	595039216	
65 A		595039155 (X5)	595039179 (X5)	OR 595039339 (Ohmic)	595039292
85 A			595039186 (X5)		
105 A	595039148		595039193 (X5)	595039223 OR 595039445 (Ohmic)	595039308

Manual GOUGING

MT-125, 6m: 595039506, 12m : 595039513

65-85 A	595039131		595039261 (X5)	595039216	
105 A	595039148	595039155 (X5)	595039278 (X5)	595039223	595039254

POUR PLUS D'INFORMATION:

Contimac bv
ZI5 Mollem 440,
1730 Asse

info@contimacgmt.be
www.contimacgmt.be